

210mm

CONNECTING

1. This set applies to AC 110V-240V, 50/60Hz
2. AC power: battery can be charged when connected to AC power. Red light on battery is charging, it will change to green once battery complete charge.
3. Internal battery will be charged even device switch off when plugged in to AC power
4. Adjust function keys to your personal audio preference.

BATTERY & CHARGING

1. The units takes approximately 8 hours to fully charge. It will automatically begin charging once the power cord is connected.
2. If the battery power is low may caused sound distortion or stop play, please charging the battery on time.
3. To maximize the battery's lifespan, please charging the battery immediately. When the unit is not used for prolonged periods of time,the battery will gradually lose its power. It is recommended to fully charge the battery at least every 30days.
4. To saving battery, please power off once stop using.

ATALAX®

USER MANUAL



MAGNA

PROFESSIONAL SPEAKER

PLEASE READ THIS USER MANUAL CAREFULLY BEFORE SYSTEM CONNECT

MADE IN CHINA

IMPORTANT SAFETY MEASURES

Before using this machine, please read all the safety and operating instructions, meanwhile, please observe all the indications about safe operating. These safety and operating instructions should be kept in condition of consultation.



1. Protection of electric power supply line: Be aware that the electric power supply line is not trapped, pressed by heavy objects. Pay special attention to the plug of power supply line and outlet on the machine. DO NOT lengthen the electric shock, DO NOT pull or drag or the power supply line.
2. Ventilation: This set must be put in ventilated place. DO NOT put disk on it or cloth to cover it. The distance away from the wall should not be less than 10 centimeters. DO NOT put this set on the bed, sofa, carpet or other objects with similar surface in case of good ventilation.
3. Casing Dismantling: DO NOT dismantle the casing. If one touches the inner components, he will probably get serious electric shock.
4. Unusual smell: When you discover unusual smell and smoke, cut power supplies immediately and pulls out the plus from the outlet on the wall. Contact the sell shop or nearest repairing center.


Attention: This set applies to AC 110V~240V / 50Hz~60Hz power supply. Use standard power supply. Please be sure for te correct power supply before use it.

PRODUCT FEATURES


- Wireless
- Plays Mp3 files stored in card drive/external audio device.
- FM radio
- Wired microphone included
- Built-in rechargeable battery
- Microphone inputs
- With remote control
- Super dynamic sound speaker

REAR PANEL FUNCTION INSTRUCTION

REMOTE CONTROL



- Standby
- USB/SD CARD/LINE (Audio input)
- Prev/FM CH-
- Play/pause/FM tuner
- Next/FM CH+
- Repeat
- Stop
- Volume up
- Volume down
- Mute
- Equalizer
- Number



MAGNA


PANEL FUNCTION

1. LED LIGHT ON/OFF SWITCH
2. POWER ON/OFF SWITCH
3. ECHO/MIC VOLUME/VOLUME ADJUST
4. USB/ SD CARD INPUT SLOT
5. MODE: MODE SELECT
6. REC: RECORDING
7. REPE: REPEAT
8. PREV: PREVIOUS TRACK
9. SCAN/PAUSE, TWS ON/OFF SWITCH(PRESS & HOLD)
10. NEXT: NEXT TRACK
11. MIC PRI.: MICROPHONE PRIORITY EFFECT ON/OFF BUTTON
12. EQUALIZER: TREBLE AND BASS ADJUST
13. AUX IN
14. MIC IN
15. BATTERY CHARGE INDICATING LIGHT
16. DC 9V IN: DC 9V CHARGING INPUT

WIRELESS INSTRUCTION

Change the mode into “BLUE”, the wireless sign light twinkles, and speaker have sound “di”. Set on mobile phone, connect to wireless data, search equipment and match properly. The proper connect wireless lights keep on, and music work on speaker normally.

TWS CONNECTION



In blue mode, press the TWS button and hold it down for three seconds, the primary speaker will sound an alarm and the screen will show "BTST". The secondary speaker switch to blue mode will automatically connect to the primary speaker, and the screen will show "BT".

210mm

148.5mm

148.5mm

148.5mm

148.5mm